Projecting your HoloLens2 view on an external screen

-v1

MaFEA – Making Future Education Accessible PR2 – Guiding successful adoption

















Projecting your HoloLens2 view on an external screen - v1

- 1. First you connect the MS display adaptor in the screen. You have to use the HDMI and a usb connection.
- 2. You make sure that your screen is connected with the right HDMI connection.



3. In the HoloLens you tab on the icon of the screen in the start menu.



4. It depend, but sometimes you have to enter a code from the screen. Than you connect.








5. When the connection is ok, the screen will project the view of the HoloLens.






How to project your HoloLens view with internet link

- 1. First you have to look for your IPv4-adress.
 - a. Go to settings
 - b. Go to network and internet and tab on Wi-Fi




c. Go to adaptor properties



2. Full in your IPv4 in the browser

NOTE, it is not a secured connection






Inloggen


Annuleren

In views you tab on Mixed Reality Capture






Click on Live preview



You see on your monitor the view of the HoloLens





You can also look for the pictures

